



HURRICANE ANCHOR - BHB

INSTALLATION GUIDE


ROOF TRUSS/RAFTER TO TOP PLATE CONNECTION



Position BHB
Anchor at the set
out point on
the top plate.




Screw fix BHB
Anchor to top plate
using (4-6) Burmon
screws




Screw fix roof
truss/rafter to BHB
Anchor using (3-4)
Burmon screws


CEILING JOIST & RAFTER TO TOP PLATE CONNECTION



Screw fix BHB
Anchor to top plate
using (4-6) Burmon
screws



Screw fix rafter
to BHB Anchor
using (3-4) Burmon
screws



Screw fix ceiling joist
to BHB Anchor
and rafter using
(3-4) Burmon screws

NOTE - To achieve the uplift and lateral load requirements for each truss/rafter:

1. Refer to Burmon website or product catalogue for number of screws and length of screws required to achieve load designs.
2. Refer to Truss company's reaction report for load design requirements for each truss.
3. Refer to Engineer for top plate and wall load design requirements.